

Plastic Locker Replacement Door Instruction Guide



Tools Required: Pliers
Hammer

Fittings Required: 12" & 18" Lockers – 4 Nylon Hinge Pins
36" Lockers – 6 Nylon Hinge Pins
60" Lockers – 10 Nylon Hinge Pins

1. Remove existing door.
2. Pull out pins with pliers. Pins are inside the locker next to the hinge area.
3. Place new door in locker body. Make sure that the door fits the opening.
4. Install new nylon hinge pins. Press into the holes, then tap with a hammer.
5. Give a slight tug to make sure pin fits snug.

